

Installation instruction

PrimaCover Construct Article no.: 900036

Non-woven covering with self-adhesive underside, integrated liquid-proof foil, as well as absorbent, upper side; diffusion closed

- ♦ Easy to install and remove, re-usable
- ♦ Robust and tear resistant
- ♦ Anti-slip



: +31 416 820 248

E: info@primaverde.nl

W. www.primaverde.nl

Application range

- ♦ For covering flat, hard surfaces when working indoors, protects the substrate from mechanical damager and moisture.
- ♦ Also suitable for stairs.
- ♦ Not suitable for porous surfaces.
- ♦ Not suitable for wet or freshly laid floors. Risk of waterlogging and associated negative changes to the floor.

Installation instruction

- ♦ The substrate must be clean, dry, pressure-resistant, dust- and grease free.
- ♦ Existing floor heating must be switched off.
- ◆ Lay the non-woven on the floor with the self-adhesive side facing downwards, without wrinkles and press down firmly.
- ♦ Cut the non-woven at edges and corners with a safety knife.
- ♦ Don not lay over cables, protruding objects or other elevations, trip hazard!
- ♦ When laying several sheets next to each other, allow them to overlap by 10cm, press firmly and, if necessary, fix with a suitable tape.

Special feature installation on stairs

- ◆ Lay out the non-woven at the top step far enough (approx. 50cm) and fix the beginning with adhesive tape to the substrate.
- ♦ Lay out the none-woven covering step by step in one go from top to bottom along the shape of the stairs, pressing the fleece on each step (tread and riser) without wrinkles.
- ♦ No moving pieces on the stairs, with exception of the spiral staircase.
- ♦ Lay the fleece on the lowest step far enough into the room and fix it.
- ♦ Regularly check the adhesion of the non-woven to the substrate.
- ♦ Check the surface of the fleece regularly and clean if necessary.
- ♦ If the non-woven is damaged, remove it and lay out new fleece, this is the only way to ensure reliable protection of the substrate.

Re-usability

- Remove impurities from the dry non -woven covering before rewinding.
- ♦ Fold the non-woven covering with the sticky side on top of each other, then rewind.
- ♦ Before re-use, check the underside for dirt and remove if necessary.

Note

- ♦ Test the suitability of the product in advance in an inconspicuous place.
- ♦ No acceptance of liability for incorrect usage.
- ♦ It is absolutely necessary to pay attention to the installation instructions and application range!
- ♦ Always store in a dry place!
- ♦ 3 Months after installation, the non-woven should be removed from the surface. It is recommended to protect the non-woven from high temperatures and strong direct sunlight, as this could affect its technical characteristics.

Disposal

The non-woven can de disposed of in landfills after use, with dried paint or plaster residues, in compliance with official regulations.