

# Installation instruction

**PrimaCover Hardfloor**

Article no.: 900090, 900664

Self-adhesive film for the temporary protection of hard surfaces

- ◆ Easy to remove
- ◆ Self-adhesive

**Application range**

- ◆ For hard surfaces only.
- ◆ For covering flat, hard surfaces when working indoors, protects the substrate from mechanical damage and moisture.
- ◆ Chemical evaporation must be completely stopped.
- ◆ Also suitable for stairs.
- ◆ Not suitable for porous surfaces.
- ◆ Not suitable for wet or freshly laid floors. Risk of waterlogging and associated negative changes to the floor.

**Installation instruction**

- ◆ The substrate must be clean, dry, pressure-resistant, dust- and grease free.
- ◆ Existing floor heating must be switched off.
- ◆ The film must be applied without wrinkles and without excessive tension.
- ◆ Cut the film at edges and corners with a safety knife.
- ◆ Don't lay over cables, protruding objects or other elevations, trip hazard!
- ◆ When laying several sheets next to each other, allow them to overlap by 10cm, press firmly.

**Note**

- ◆ Test the suitability of the product in advance in an inconspicuous place.
- ◆ No acceptance of liability for incorrect usage.
- ◆ It is absolutely necessary to pay attention to the installation instructions and application range!
- ◆ Always store in a dry place!
- ◆ 4 Weeks after installation, the film should be removed from the surface. It is recommended to protect the film from high temperatures and strong direct sunlight, as this could affect its technical characteristics.

**Disposal**

The protective film can be recycled after use in the appropriate container for LDPE, in accordance with government requirements.