

## **User Manual – PrimaCover Film Dispenser**

For quick, ergonomic, and precise application of protective film.

### **1. Preparation**

- Choose the correct film: suitable for rolls 62.5 cm wide, thickness 50 or 100 microns.
- Place the film roll in the dispenser, with the film facing downward toward the surface.
- Ensure the roll is securely positioned and can rotate freely.

### **2. Adjusting the Handle**

- For large surfaces: use the telescopic handle (1–2 meters) and set it to a comfortable working height.
- For stairs or hard-to-reach areas: use the dispenser without the handle, using the ergonomic grip.
- Click the handle into the grip for compact transport.

### **3. Applying the Film**

- Place the beginning of the film onto the surface.
- Slowly push the dispenser forward in a straight line.
- The film will automatically unroll and lay flat and firmly on the surface.
- For long runs or corners: maintain slight tension on the film for a smooth result.

### **4. After Use**

- Cut the film with a suitable film cutter or scissors.
- Remove the film roll if needed and store the dispenser in a dry place.
- Clean the dispenser, especially after use in dusty or dirty environments.

**Note: For optimal results, the surface should be dry, dust-free, and grease-free.**

- **Test the suitability of the product beforehand.**
- **No liability is accepted for improper use.**